RPe SERIES MOBILE PRINTERS
ACCESSORIES GUIDE

Honeywell

TABLE OF CONTENTS

CHARGERS AND BRACKETS

229041-000

Charger with Retrofit Adapter

Charger with retrofit adapter for MF4Te charger enables users of MF4Te charging brackets to use existing adapter installations for both legacy MF and RP2e-RP4e Series. Regional power supply needs to be ordered separately.

229042-000

Charger with Single Wall Adapter Kit

Single printer settlement room or a depot mounting bracket enables a single charger to be mounted on the wall or as a desktop application. The printer may be charged in an organized manner with the charging dock removed from busy work areas. Available for both RP2e and RP4e mobile printers. Regional power supply needs to be ordered separately.

229045-000

RP2e Vehicle-Mount Bracket Charger

An optional accessory designed to both charge the printer as well as keep the printer secure, yet easily accessible, on a forklift or other vehicle. To charge the printer in a vehicle, we have the following power supply options:

510116-001 – Lighter receptacle adapter

220282-000 – 12 V power converter, 48 V to 60 V forklift

229044-000

RP4e Vehicle-Mount Bracket Charger

An optional accessory designed to both charge the printer as well as keep the printer secure, yet easily accessible, on a forklift or other vehicle. To charge the printer in a vehicle, we have the following power supply options:

510116-001 – Lighter receptacle adapter

220282-000 – 12 V power converter, 48 V to 60 V forklift

229043-000

Settlement Room Mounting/Charging Bracket

Multi-charger settlement room or a depot mounting bracket enables up to five (5) RPe printers to be mounted on the wall or as a desktop application. They may be charged in an organized manner with the charging dock. Power supply is integrated; only a regional power cord needs to be ordered.

220540-000

Four-Bay Smart Battery Charger

The four-bay battery charger is a compact charger used to charge RPe Series 4-cell and 2-cell battery packs. This enables the workforce to have charged batteries ready for a full fleet of products. Power supply is not included. Please order 50121667-001 separately.

RP2-QD-0

Four-Bay Charging Dock

The four-bay charging dock charges up to four RP2e Series mobile printers. Power supply is not included. Please order 50121667-001.

Sold separately: not included.

RP4-QD-0

Four-Bay Charging Dock

The four-bay charging dock charges up to four RP4e Series mobile printers. Power supply is not included. Please order 50121667-001.

Sold separately: not included.

BATTERY PACKS

50133975-001

RP2 Spare Battery

Battery for RP2 printer.

550053-000

RP4 Spare Battery

Battery for RP4 printer.

211288-000

RP2e Battery Eliminator

For tabletop applications where the printer does not need a battery, use a battery eliminator accessory.

211289-000

RP4e Battery Eliminator

For tabletop applications where the printer does not need a battery, use a battery eliminator accessory.

CASES

50134863-001

RP2e Environmental Soft Case

Thermal soft case used in harsher environments to provide dust and cold protection. Shoulder strap is not included. Please order 210302-000 separately.

750336-000

RP4e Environmental Soft Case

Thermal soft case used in harsher environments to provide dust and cold protection. Shoulder strap is not included. Please order 210302-000 separately.

MISCELLANEOUS ACCESSORIES

280797-000

Swivel Belt Clip (RL Style)
Standard belt clip, included in the box with both the RPe Series and RL Series.

210305-000

Velcro Belt Mount (RL Style)

210302-000

Shoulder Strap

220515-100

AC Adaptors
With correct regional plug 12 V at 1.66 A, US plug.

220516-100

Euro Plug

220517-100

UK Plug

220518-100

Australia Plug

220521-100

Swiss Plug

210304-100

USB Cable

510116-001

Lighter Receptacle Adaptor

For more information

www.honeywellaidc.com

Honeywell Safety and Productivity Solutions

9680 Old Bailes Road
Fort Mill, SC 29707
800-582-4263
www.honeywell.com

THE FUTURE IS WHAT WE MAKE IT
—

Honeywell